



SAFE AGE



DIGITAL CALENDAR  
ALARM DAY CLOCK

USER'S MANUAL



## MAIN FUNCTION



Support  
Clock  
Function



Support  
Remote  
Control



Digital Picture,  
Video and Music  
Function



Support  
Alarm Clock  
Function

## CLOCK

### 1.CLOCK MENU

- 1.1 Enter the clock menu by pressing the menu button on the device or the setup button on the remote control and set the time.

## ALARM CLOCK

### 2.ALARM MENU

- 2.1 Enter the Alarm menu by pressing the menu button on the device or the setup button on the remote control and set the Alarm Status.

### 3.ALARM SETTING

- 3.1 Add or set the timer. Enter the time, day and reminder description (tag) of the timer. Switch the timer on to make it active. You can add multiple timers if you want.

## SETTINGS

### 4.CLOCK SETTINGS

- 4.1 Press the menu key on the device or the setup key on the remote to enter the setup menu. Then press [▲] [▼] to select the settings. Press the OK/ENTER key to enter the settings. Then press [◀] [▶] to change the setting of date, time and press the [▲] [▼]. When setting is complete press OK or BACK to exit.
- 4.2 The brightness can be customized from level 1-5. Automatic brightness is 5 levels during the day and 1 level brightness at night.

## PLAY FUNCTION

### 5.VIDEO, PICTURE + MUSIC PLAYBACK

- 5.1 Press the confirmation key after key to play the video, picture, music after placing USB or SD card.

Note: Please use genuine SD card/U disk.

Show your colorful life  
Digital photo frame  
Made in China



SAFE AGE



KALENDERKLOK

GEBRUIKERSHANDLEIDING



## HOOFDFUNCTIE



Klok  
Functie



Wekker  
Functie



Afstandsbediening  
Controle



Foto, video &  
muziek functie

## KLOK

### 1. KLOKMENU

- 1.1 Open het klokmenu door op de menuknop van het apparaat of de setup toets van de afstandsbediening te drukken en stel de tijd in.

## ALARM KLOK

### 2. ALARM-MENU

- 2.1 Ga naar het alarmmenu door op de menuknop op het apparaat of de insteltoets op de afstandsbediening te drukken en stel de alarmstatus in.

### 3. ALARM INSTELLINGEN

- 3.1 Voeg de timer toe of stel deze in. Voer de tijd, dag en herinneringsomschrijving (tag) van de timer in. Schakel de timer in om hem actief te maken. U kunt meerdere timers toevoegen als u dat wilt.

## INSTELLINGEN

### 4. KLOKINSTELLINGEN

- 4.1 Druk op de menu toets op het apparaat of op de setup toets op de afstandsbediening om het instellingen menu te openen. Druk vervolgens op [▲] [▼] om de instellingen te selecteren. Druk op de OK/ENTER toets om de instellingen te openen. Druk vervolgens op [◀] [▶] om de instelling van datum en tijd te wijzigen en druk op [▲] [▼]. Wanneer de instelling voltooid is, drukt u op OK of TERUG om af te sluiten.
- 4.2 De helderheid kan worden aangepast van niveau 1-5. Ook kunt u kiezen voor automatische helderheid. Dit zijn 5 niveaus overdag en 1 helderheid niveau nachts.

## SPELEN FUNCTIE

### 5. VIDEO, FOTO + MUZIEK AFSPLEN

- 5.1 Druk na het plaatsen van een USB stick of SD kaart op de OK knop om afspelen te starten. Druk op de pijltjes om het volume en de bestanden te wijzigen.

**Opmerking: Gebruik een originele SD-kaart/USB stick.**

Toon uw kleurrijke leven  
Digitaal fotolijstje  
Gemaakt in China